


SENTINEL TM Connector Systems Inc.


Termination Instructions for 111-08080054L34



















9. Insert into Plug Housing. Push



