



Aros con Flecha Ring With Pointers

MOD. TYPE	D	e	H
10	8	6,5	8,5
15	11	10	13
21	18	15,7	19,5
30	25,5	23,8	28
38	33,5	30,5	36,5




Cubretuercas Nut Covers

MOD. TYPE	A	B	D
10	3,5	2,5	14
15	4	3	17




Discos con Flecha Dials With Pointer

MOD. TYPE	D	d	e
15	26	9,8	2,8
21	36	16	2,8
30	45	21,5	2,8
38	55	27	2,7



Discos Graduados Graded Dials

MOD. TYPE	D	d	e
15	26	9,8	2,8
21	36	16	2,8
30	45	21,5	2,8
38	55	27	2,7



Starters

CÓD. CODE	MOD. TYPE	D
BOS014	15	26
BOS021	21	36
BOS029	30	44

